


PC 模块拷贝备份文件并恢复备份步骤说明： Instruction of PC module copy and restore process of backup document

1. 准备好 U 盘 (U 盘里边有 0128 生产时 PC 模块的备份文件)

Prepare USB flash disk which contains backup document of PC module

2. 将客户端的 PC 模块，上电，将 BACKUP_OS 中的文件永久删除



Power on the PC module of customer, delete the files in BACKUP_OS
permanently




3. 将带有备份文件的 U 盘，接到这个 PC 模块上，然后复制到 BACKUP_OS 这个分区

Connect PC module with USB flash disk which contains backup document,

copy the backup document in BACKUP_OS zone





4. 复制完成后，执行拔除 U 盘进入恢复备份

Remove the USB flash disk after the copy is completed, then start the backup
restore process

恢复备份步骤如下： (耗时 30 分钟左右)


Backup restore process as below(Take about 30 minutes)

- 重启 PC 模块并按 F2 进入 BIOS

Reboot PC module and press F2 to enter BIOS


- 选择 “Advanced”并将 “OS Back up and os recovery”设置为 “Enabled”

Choose “Advanced” and set “OS Back up and os recovery” as “Enabled”




- 按 F10 保存修改并退出后自动重启

Press F10 to save the modification then exit, it will restart automatically



- 重启按 F2 进入 BIOS，然后按 F4 进行系统还原

Press F2 to enter BIOS, then press F4 to restore the system



- 还原后进入系统 安装 PC 全家桶即可

After restoration is completed, enter the system and install all MAXHUB PC software